

BME68X Project Test Report

Date: 25 March 2025

1. Executive Summary

This report details the test procedures, observations, and outcomes for the BME68X sensor-based odor classification project. The testing aimed to validate sensor baseline stability, dynamic odor transitions, and the overall performance of the firmware and Python-based data processing system. Through a series of controlled experiments involving air and three distinct odor samples (dry tea, regular instant coffee grounds, and Arabian coffee grounds), the project's ability to classify odors using a RandomForest classifier was evaluated.

2. Test Setup and Environment

Hardware and Software Configuration

- **Hardware:**
 - The BME68X sensor board was set up following the project repository instructions.
 - The board was connected to the computer via the appropriate serial port.
 - An SD card containing the configuration file for heater profiles was used to dynamically load sensor settings, with heater_354 located in the config folder inside the C++ code directory.
- **Odor Samples:**
 - **Odors Tested:**
 - **Tea:** Prepared using two tea bags (used dry, without water, so only the dry tea material is exposed).
 - **Regular Coffee:** Prepared using 2 teaspoons of regular instant coffee grounds, used dry.
 - **Arabian Coffee:** Prepared using 2 teaspoons of Arabian coffee grounds, used dry.
 - **Sample Isolation:**

Each odor sample was sealed in a clean zip lock bag to ensure that no other smells were present and to maintain sample integrity during testing.
- **Software:**
 - The data collection program was launched, and the board was connected using the correct port.
 - A configuration file with the desired heater configurations and duty profiles was sent before starting the data logging.
 - The logging session was initiated with the file name `tea_coffee_test_25_03_2025`.
- **Visual Documentation:**
 - Photographs were taken of the sensor display:

- Initial photos for the first two sensors.
 - Final photos covering all eight sensors at the end of the initial baseline period.
-

3. Test Procedure

3.1 Baseline Recording

- **Objective:** Establish a sensor baseline in clean air.
- **Procedure:**
 - Data collection commenced by logging air-only sensor readings for 5 minutes.
 - Baseline readings were captured and visually documented to ensure sensor stability.

3.2 Odor Exposure and Transition

- **Odor 1: Tea**
 - The tea odor sample was introduced.
 - Data was recorded continuously until sensor readings stabilized (approximately 25 minutes).
 - After stabilization, the odor sample was removed, and the sensor was exposed to air for 5 minutes to allow readings to return toward baseline.
 - **Odor 2: Regular Coffee**
 - After the air exposure period, the regular coffee odor sample was introduced.
 - Sensor data was recorded for another 25 minutes until stabilization was observed.
 - A subsequent 5-minute air exposure period was implemented to record the sensor's return to baseline.
 - **Odor 3: Arabian Coffee (Final Odor)**
 - The final odor sample was introduced, and data was recorded for 25 minutes.
 - An additional 5-minute air exposure period followed before stopping the data logging.
-

4. Observations and Results

Sensor Response and Stabilization

- **Baseline Stability:**

The sensors provided consistent readings during the initial 5-minute air baseline period, ensuring a reliable starting point for subsequent tests.
- **Odor Stabilization:**
 - Each odor sample required approximately 25 minutes for the sensor readings to stabilize.
 - Visual and logged data confirmed that the sensors captured the characteristic response curve for each odor.
- **Air Transition Effects:**

- It was observed that when transitioning from an odor to air, the sensor output did not immediately reflect an air baseline.
- The delayed return to baseline (after odor peaks) affected the classification of “air” as an odor.
- **Real-Time Classification:**
 - The real-time odor classification functionality operated as expected.
 - However, adequate time should be allowed for the sensors to transition from one odor to another to ensure accurate classification during real-time operation.

System and GUI Performance

- **Firmware and Command Handling:**
 - All sensor commands (e.g., **START**, **STOP**, **GETHEAT**, and configuration uploads) operated as expected.
 - Button actions effectively changed heater profiles and odor label counters, providing immediate feedback via LED indicators and serial responses.
- **Graphical User Interfaces:**
 - The Data Logger GUI successfully connected to the board, displayed real-time sensor data, and logged the experiment data accurately.
 - The Model Trainer & Predictor GUI was effective in facilitating data loading, feature extraction, and model training for odor classification.
- **Odor Classification:**
 - The RandomForest classifier reliably differentiated between the odor samples.
 - Although the system accurately classified odors based on stabilized sensor data, the prolonged recovery time for air signals suggests that model parameters may need adjustment for rapid transition scenarios.

5. Analysis and Conclusions

- **System Integration:**

The combined firmware and Python-based modules successfully managed sensor operations, real-time data logging, and subsequent odor classification. The integrated use of dynamic heater profiles and serial command handling provided a robust testing platform.
- **Sensor Response Characteristics:**

The experiments highlighted the sensors' inherent delay in returning to baseline after odor exposure. This phenomenon affects how quickly the system can detect a return to “air” and should be considered in future iterations of the classification model.
- **Real-Time Operation:**

The real-time classification worked as expected; however, it is crucial to allow sufficient time for sensor readings to transition from one odor to another, ensuring accurate prediction during rapid odor changes.

- **GUI and User Interaction:**

Both the Data Logger GUI and the Model Trainer & Predictor GUI were instrumental in monitoring and analyzing sensor data, confirming the system's performance under varied odor conditions.
